

ICOM

CHANNEL LIST 1

MF/HF MARINE TRANSCEIVER

IC-M804

Thank you for choosing this Icom product.
This channel list shows factory preset frequencies and names. If your transceiver contains different frequencies, your dealer may have a printout of frequencies entered into the transceiver.

Emergency frequency list

Frequency band	Radiotelephone	DSC	Radiotelex
MF	2182.0	2187.5	2174.5
HF4	4125.0	4207.5	4177.5
HF6	6215.0	6312.0	6268.0
HF8	8291.0	8414.5	8376.5
HF12	12290.0	12577.0	12520.0
HF16	16420.0	16804.5	16695.0

NOTE:

- ←: Same as the RX frequency.
- : Nothing is set.
- Frequencies are all in kHz.



User channels (Dealer settable)

Channel No.	RX frequency	TX frequency	Mode	Channel name
1	2182.0	←	J3E	EMERGENCY
2	4125.0	←	J3E	EMERGENCY
3	6215.0	←	J3E	EMERGENCY
4	8291.0	←	J3E	EMERGENCY
5	12290.0	←	J3E	EMERGENCY
6	16420.0	←	J3E	EMERGENCY
7	5000.0	—	H3E	WWV
8	10000.0	—	H3E	WWV
9	15000.0	—	H3E	WWV
10	2450.0	2003.0	J3E	—
11	2506.0	2406.0	J3E	—
12	4357.0	4065.0	J3E	—
13	4402.0	4110.0	J3E	—
14	4405.0	4113.0	J3E	—
15	8728.0	8204.0	J3E	—
16	8743.0	8219.0	J3E	—
17	8782.0	8258.0	J3E	—
18	13077.0	12230.0	J3E	—
19	13080.0	12233.0	J3E	—
20	13083.0	12236.0	J3E	—
21	17245.0	16363.0	J3E	—
22	17248.0	16366.0	J3E	—
23	17311.0	16429.0	J3E	—
24	22735.0	22039.0	J3E	—
25	22762.0	22066.0	J3E	—
26	22777.0	22081.0	J3E	—
27	22801.0	22105.0	J3E	—
28	2490.0	2031.5	J3E	—
29	2442.0	2406.0	J3E	—
30	2514.0	2118.0	J3E	—
31	2566.0	2390.0	J3E	—
32	4363.0	4071.0	J3E	—
33	4390.0	4098.0	J3E	—
34	4405.0	4113.0	J3E	—
35	4423.0	4131.0	J3E	—
36	8722.0	8198.0	J3E	—
37	8731.0	8207.0	J3E	—
38	8746.0	8222.0	J3E	—
39	8758.0	8234.0	J3E	—
40	8791.0	8267.0	J3E	—

Channel No.	RX frequency	TX frequency	Mode	Channel name
41	8809.0	8285.0	J3E	—
42	13092.0	12245.0	J3E	—
43	13098.0	12251.0	J3E	—
44	13101.0	12254.0	J3E	—
45	13119.0	12272.0	J3E	—
46	13143.0	12296.0	J3E	—
47	13164.0	12317.0	J3E	—
48	17242.0	16360.0	J3E	—
49	17266.0	16384.0	J3E	—
50	17269.0	16387.0	J3E	—
51	17272.0	16390.0	J3E	—
52	17287.0	16405.0	J3E	—
53	22738.0	22042.0	J3E	—
54	22741.0	22045.0	J3E	—
55	22759.0	22063.0	J3E	—
56	2450.0	2366.0	J3E	—
57	2558.0	2166.0	J3E	—
58	2561.0	2169.0	J3E	—
59	4384.0	4092.0	J3E	—
60	4387.0	4095.0	J3E	—
61	4402.0	4110.0	J3E	—
62	4420.0	4128.0	J3E	—
63	8740.0	8216.0	J3E	—
64	8749.0	8225.0	J3E	—
65	8761.0	8237.0	J3E	—
66	8794.0	8270.0	J3E	—
67	13083.0	12236.0	J3E	—
68	13104.0	12257.0	J3E	—
69	13107.0	12260.0	J3E	—
70	13158.0	12311.0	J3E	—
71	17254.0	16372.0	J3E	—
72	17299.0	16417.0	J3E	—
73	17317.0	16435.0	J3E	—
74	17332.0	16450.0	J3E	—
75	22696.0	22000.0	J3E	—
76	22708.0	22012.0	J3E	—
77	22723.0	22027.0	J3E	—
78	22801.0	22105.0	J3E	—
79	2065.0	←	J3E	—
80	2079.0	←	J3E	—

■ User channels (Dealer settable)

Channel No.	RX frequency	TX frequency	Mode	Channel name
81	2096.5	←	J3E	–
82	3023.0	–	J3E	–
83	4125.0	←	J3E	–
84	4164.0	←	J3E	–
85	4149.0	←	J3E	–
86	4417.0	←	J3E	–
87	5680.0	–	J3E	–
88	6224.0	←	J3E	–
89	6227.0	←	J3E	–
90	6230.0	←	J3E	–
91	6516.0	←	J3E	–
92	8294.0	←	J3E	–
93	8297.0	←	J3E	–
94	12353.0	←	J3E	–
95	12356.0	←	J3E	–
96	12359.0	←	J3E	–
97	16528.0	←	J3E	–
98	16531.0	←	J3E	–
99	16534.0	←	J3E	–
100	18840.0	←	J3E	–
101	18843.0	←	J3E	–
102	22159.0	←	J3E	–
103	22162.0	←	J3E	–
104	22165.0	←	J3E	–
105	22168.0	←	J3E	–
106	22171.0	←	J3E	–
107	25115.0	←	J3E	–
108	25118.0	←	J3E	–
109	2070.5	←	J3E	–
110	2072.5	←	J3E	–
111	2074.5	←	J3E	–
112	2076.5	←	J3E	–
113	4154.5	←	J3E	–
114	4169.5	←	J3E	–
115	6235.5	←	J3E	–
116	6259.5	←	J3E	–
117	8302.5	←	J3E	–
118	8338.5	←	J3E	–
119	12370.4	←	J3E	–
120	12418.5	←	J3E	–

Channel No.	RX frequency	TX frequency	Mode	Channel name
121	16551.5	←	J3E	–
122	16614.5	←	J3E	–
123	18847.5	←	J3E	–
124	18868.5	←	J3E	–
125	22181.5	←	J3E	–
126	22238.5	←	J3E	–
127	25123.5	←	J3E	–
128	25159.5	←	J3E	–
129	2003.0	←	J3E	–
130	2006.0	←	J3E	–
131	2030.0	←	J3E	–
132	2054.0	←	J3E	–
133	2065.0	←	J3E	–
134	2079.0	←	J3E	–
135	2082.5	←	J3E	–
136	2086.0	←	J3E	–
137	2093.0	←	J3E	–
138	2096.5	←	J3E	–
139	2115.0	←	J3E	–
140	2118.0	←	J3E	–
141	2134.0	←	J3E	–
142	2142.0	←	J3E	–
143	2182.0	←	J3E	–
144	2203.0	←	J3E	–
145	2419.0	←	J3E	–
146	2422.0	←	J3E	–
147	2427.0	←	J3E	–
148	2430.0	←	J3E	–
149	2447.0	←	J3E	–
150	2450.0	←	J3E	–
151	2479.0	←	J3E	–
152	2482.0	←	J3E	–
153	2506.0	←	J3E	–
154	2509.0	←	J3E	–
155	2527.0	←	J3E	–
156	2535.0	←	J3E	–
157	2638.0	←	J3E	–
158	2738.0	←	J3E	–
159	–	–	–	–
160	–	–	–	–

■ DSC Frequencies (Dealer settable)

Channel No.	Use	RX frequency	TX frequency	Channel name
1	Call	2177.0	←	SHIP
2	Call	2177.0	2189.5	INTER2-1
3	Call	4219.5	4208.0	INTER4-1
4	Call	4220.0	4208.5	INTER4-2
5	Call	4220.5	4209.0	INTER4-3
6	Call	6331.0	6312.5	INTER6-1
7	Call	6331.5	6313.0	INTER6-2
8	Call	6332.0	6313.5	INTER6-3
9	Call	8436.5	8415.0	INTER8-1
10	Call	8437.0	8415.5	INTER8-2
11	Call	8437.5	8416.0	INTER8-3
12	Call	12657.0	12577.5	INTER12-1
13	Call	12657.5	12578.0	INTER12-2
14	Call	12658.0	12578.5	INTER12-3
15	Call	16903.0	16805.0	INTER16-1
16	Call	16903.5	16805.5	INTER16-2
17	Call	16904.0	16806.0	INTER16-3
18	Call	19703.5	18898.5	INTER18-1
19	Call	19704.0	18899.0	INTER18-2
20	Call	19704.5	18899.5	INTER18-3
21	Call	22444.0	22374.5	INTER22-1
22	Call	22444.5	22375.0	INTER22-2
23	Call	22445.0	22375.5	INTER22-3
24	Call	26121.0	25208.5	INTER25-1
25	Call	26121.5	25209.0	INTER25-2
26	Call	26122.0	25209.5	INTER25-3
27	–	–	–	–
28	–	–	–	–
29	–	–	–	–
30	–	–	–	–
31	–	–	–	–
32	–	–	–	–
33	–	–	–	–
34	–	–	–	–
35	–	–	–	–
36	–	–	–	–
37	–	–	–	–
38	–	–	–	–
39	–	–	–	–
40	–	–	–	–
41	–	–	–	–
42	–	–	–	–
43	–	–	–	–
44	–	–	–	–
45	–	–	–	–
46	–	–	–	–
47	–	–	–	–
48	–	–	–	–
49	–	–	–	–
50	–	–	–	–

Channel No.	Use	RX frequency	TX frequency	Channel name
51	–	–	–	–
52	–	–	–	–
53	–	–	–	–
54	–	–	–	–
55	–	–	–	–
56	–	–	–	–
57	–	–	–	–
58	–	–	–	–
59	–	–	–	–
60	–	–	–	–
61	–	–	–	–
62	–	–	–	–
63	–	–	–	–
64	–	–	–	–
65	–	–	–	–
66	–	–	–	–
67	–	–	–	–
68	–	–	–	–
69	–	–	–	–
70	–	–	–	–
71	–	–	–	–
72	–	–	–	–
73	–	–	–	–
74	–	–	–	–
75	–	–	–	–
76	–	–	–	–
77	–	–	–	–
78	–	–	–	–
79	–	–	–	–
80	–	–	–	–
81	–	–	–	–
82	–	–	–	–
83	–	–	–	–
84	–	–	–	–
85	–	–	–	–
86	–	–	–	–
87	–	–	–	–
88	–	–	–	–
89	–	–	–	–
90	–	–	–	–
91	–	–	–	–
92	–	–	–	–
93	–	–	–	–
94	–	–	–	–
95	–	–	–	–
96	–	–	–	–
97	–	–	–	–
98	–	–	–	–
99	–	–	–	–
100	–	–	–	–